



3

Perform the in-app setup



## Step 1

### Follow the in-app setup process

In the Ring app, select the option to add a new device. When prompted, select **Video Doorbell Pro**, and follow the in-app instructions.



## Step 2

### Install the faceplate

Secure one of the faceplates with a security screw, using the star-shaped end of your Ring screwdriver.

2



### Shared Users

To let family or friends answer live events and view recordings (if cloud recording is enabled), select Shared Users on the settings screen of the Ring app, and enter their email(s).



### Motion Detection

Motion detection is disabled by default.

To enable and customize motion detection, select Motion Settings on the settings screen of the Ring app.

3



### Cloud Video Recording

This optional feature saves events captured by your Ring Doorbell Pro.

You can view, download, and share these events on any device running the Ring app, or at: [ring.com/activity](https://ring.com/activity)



### Live View

Select the **Live View** button on the settings screen of the Ring app to access a live stream of video from your Ring Doorbell Pro at any time.

4



When someone's at your door, or if motion is detected, you can perform the following actions:

-  **Disable/enable your microphone**
-  **Zoom in/out**
-  **Mute/unmute sound in the app**
-  **Access the Ring Plus menu**




You can toggle alerts for rings or motions on or off in the Ring app.



The front light on your Ring Doorbell Pro uses various patterns to communicate messages.

Here are some common ones:

- In Setup Mode**  White Spinning
- Powered**  White Solid
- Front Button Pushed**  Blue Spinning
- Ring Speaker Enabled**  Blue Solid
- Updating Software**  White Flashing



## Stick Up Cam

When used with Ring Doorbell, Stick Up Cam provides a Ring of Security around your home.

This self-install security system enables you to monitor and interact with anyone on your property, no matter where you are.

Learn more at:  
[ring.com/stickupcam](http://ring.com/stickupcam)

For additional help, visit: [ring.com/help](http://ring.com/help)

For immediate assistance, we're available 7 days a week at: [help@ring.com](mailto:help@ring.com)

**US 1 800 656 1918**

**UK 01727 263045**

**AU 1 300 205 983**

**NZ +64 9 887 9871**

**Mexico (D.F) 52 55 8526 5445**

**Worldwide +1 310 929 7085**

For a list of all our customer support numbers, visit: [ring.com/callus](http://ring.com/callus)

**ring** 1523 26th St.  
Santa Monica, CA 90404

**CE**<sup>0682</sup> Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at [www.ring.com/DoC.pdf](http://www.ring.com/DoC.pdf).

Protect the device from direct sunlight. Install the device at dry locations and protect it against rain and humidity. The device may not get contact to salt water or other conductive liquids. The device must be charged only within a building in a dry state.

Caution: Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions.

© 2016 Bot Home Automation, Inc.

RING, ALWAYS HOME, and CHIME are trademarks of Bot Home Automation, Inc.

Last updated: 01/18/18